

# RB217(CE)


EXPLODED  
VIEW AND SPARE  
PARTS LIST

EINZELTEILDAR-  
STELLUNG UND  
ERSATZEILLISTE

SCHEMA ECLATE ET  
LISTE DES PIÉCES  
DE RECHANGE

ESPLOSO DEI  
COMPONENTI DE  
ELENCO DELLE  
PARTI DI RICAMBIO

DESPIECE DE LA  
MAQUINA Y LISTA  
DE RECAMBIOS



## RB217 - Parts List

Part No.	Part Code	Description
1	BB40481	BOLT 3X5
2	EE31122	WASHER 3X7
3	RB12229	ARM B
4	RB12230	WARE GUIDE B
5	FF41724	PIN 1724
6	JJ10109	E-RING 2
7	RB12090	CUTTER LEVER B(397)
8	JJ10514	E-RING 3 CF
9	RB10379	FIXED CUTTER
10	FF51686	PIN 1686
11	RB11846	SHAFT
12	RB10378	CUTTER
13	RB10392	PIN
14	AA22005	SCREW M3X5
15	RB10525	WIRE GUIDE A
16	RB70517	ARM A UNIT
17	RB12228	CUTTER LEVER A
18	RB12231	CONNECTING ROD
19	RB10540	LEAF SPRING
20	AA25113	PAN-HEAD SCREW 2X4
21	RB70516	ARM ASSY (RB217)
22	KK33370	SPRING 3370
23	RB12003	SCREW
24	RB12007	PIPE SPONGE
26	JJ10101	E-RING 4
27	RB81207	PIPE ASSY (RB217)
28	RB70511	CURL GUIDE UNIT (217)
29	RB12010	CURL GUIDE COVER
30	KK33365	TORSION SPRING
31	RB11708	STOPPER SHAFT
32	RB70510	CURL GUIDE ASSY (RB217)
33	RB11102	HOOK
34	RB81113	WS PIN 2.5X10
35	RB12014	KEY B
36	RB12017	SLEEVE A
37	RB12016	SLEEVE GUIDE
38	RB70377	TIP AXIS B
39	RB10115	KEY B
40	KK23730	COMP. SPRING 3730
41	RB12018	TIP AXIS A
42	RB12015	SLEEVE B
43	RB70412	CUTTER RING UNIT
44	RB12091	CUTTER RING GUIDE
45	JJ21011	C-RING 14
46	RB81176	TIP AXIS ASSY
47	RB12020	SPRING COLLAR
48	KK29026	COMP. SPRING 9026
49	RB12019	BUMPER
50	RB81177	TIP AXIS GUIDE ASSY
51	JJ21603	C-RING 20
52	RB10338	INTERNAL GEAR
53	LL11181	WHEEL 6704
54	RB70408	PLANETCAGE UNIT
55	FF31589	PIN 1589
56	RB10341	PLANET GEAR
57	RB10484	GEAR PRESS WHEEL
58	RB70418	SUN GEAR UNIT
59	RB70413	TWISTING MOTOR RS-550VF
60	AA21419	SCREW 3X8
61	FF51817	HOLLOW PIN 1817
63	RB81246	REEL GUIDE ASSY
64	RB12284	REEL GUIDE

65	AA05555	SCREW 3X6 CF
66	RB11687	NUT PLATE
67	BB41706	BOLT 4X10
68	FF31563	PIN 1563
69	KK34089	SPRING 4089
70	RB81181	RATCHET COVER ASSY
71	BB40425	BOLT 3X10
72	RB12100	WARNING LABLE A
73	RB70401	MOTOR COVER ASSY(397CE)
74	FF41821	STEP PIN 1821
75	KK34067	TORSION SPRING 4067
76	EE39609	RUBBER WASHER 1.8X6X2
77	BB40515	BOLT 3X50
78	RB12031	JOINT
80	RB81178	REEL HOLDER ASSY
81	RB81179	REEL MAGAZINE
82	RB12038	REEL STOPPER SPRING
83	EE39907	WASHER 3.1X12X0.8
84	RB12035	REEL STOPPER
85	FF21240	PIN 2.5X6
86	RB12036	STOPPER PLATE
87	RB70427	REEL STOPPER
88	RB81180	REEL MAGAZINE ASSY
89	RB12099	PLATE B
90	BB41707	BOLT 4X16
91	EE11103	SPRING WASHER 2-4
92	EE39825	WASHER 4.5X7.4X0.8
93	KK24175	COMP. SPRING 4175
94	JJ10113	E-RING 2.5
95	RB10359	FEEDING GEAR B2
96	RB10362	RELEASE LEVER
97	FF41809	STEP PIN 1809
98	FF51628	HOLLOW PIN 1628
99	EE32104	WASHER 2-3
100	RB10357	FEEDING GEAR B1
102	RB10364	WIRE GUIDE C
103	CC41104	HEX.NUT 1-3 FOR HD-12/17
104	RB70434	PARTITION PLATE
105	RB12045	PARTITION SPONGE
106	RB12044	SPONGE SUPPORT
107	RB70509	FEEDING GEAR A ASSY
108	RB81174	FEEDING MOTOR ASSY
109	RB81183	FEEDING ASSY
110	RB10368	JAW A
111	KK33249	TORSION SPRING 3249
112	RB10370	JAW BASE
113	FF41822	STEP PIN 1822
114	RB10369	JAW B
115	RB70495	JAW BASE ASSY
116	RB12238	ROTARY PIN
117	RB81185	SOLENOID ASSY
118	FF41855	PIN 1855
119	JJ10106	E-RING 6
120	RB12030	PALTE C
121	RB12029	ROTARY PLATE
122	FF21620	PIN 2X12
123	RB70531	BRAKE ASSY
124	BB40712	BOLT 4X8
125	RB12025	REEL PRESS
126	KK33373	SPRING 3373
127	FF52114	HOLLOW PIN 2114
128	RB70457	MAIN SWITCH UNIT(RB397)
129	RB12234	DIAL LABEL
131	RB81209	SWITCH BASE ASSY (RB217)
132	RB12054	STEP PIN
133	RB12053	RELEASE STOPPER

134	RB12055	STOPPER BASE
135	RB12056	SPONGE F
136	RB81139	STOPPER BASE ASSY
137	KK23561	COMPRESSION SPRING 3561
138	BB40710	BOLT 3X8
140	BB40709	BOLT 3X16
141	RB12236	PLATE A
142	CC42512	HEX NUT 1A M4
143	RB12098	WARNING LABEL
145	FF52111	PIN 2111
146	BB41503	BOLT 3X8
147	RB12226	COVER (RB217)
148	RB70514	FRAME L ASSY (RB217)
149	RB11987	WINDOW
150	RB81195	RELAY BOARD UNIT
151	RB81191	SENSOR CIRCUIT D BOARD UNIT
152	AA31724	SCREW 2X8
153	RB12080	TRIGGER (397)
154	KK23656	COMPRESSION SPRING 3656
155	RB12101	TRIGGER LOCK LEVER(397)
156	RB70453	TRIGGER AWITCH UNIT(RB397)
157	RB70473	SWITCH LEVER UNIT
158	KK34083	SPRING 4083
159	RB11686	SWITCH LEVER PIN
160	RB70522	MAIN CIRCUIT BOARD UNIT (RB217)
161	RB70465	REPLAY BOARD HARNESS UNIT(RB39
162	RB70454	INTERFACE HARNESS UNIT(RB397
163	RB81188	ELECTRODE UNIT
164	RB70464	BATTERY SIGNAL HARNESS UNIT
165	RB12224	COVER R (RB217)
166	RB11983	LABEL CURL GUIDE
167	RB11985	USAGE LABEL
168	RB12237	LABEL, MAIN SWITCH
169	RB12225	
171	RB70513	FRAME R ASSY (RB217)
172	BB40810	BOLT 3X16
173	RB81184	BELT HOOK ASSY
174	RB12039	LED COVER
175	BB41708	BOLT 4X10
176	AA31722	SCREW 3X8
177	AA31721	SCREW 3X6
178	RB11141	REAF SPRING GUIDE
999	PJ70058	LATCH ASSY