




Repère	Code	Français	English	Deutsch
101	12B03553	Vis CHC M3-6	Hex.Soc.Hd.Bolt	Schraube
102A	12B03554	Bras complet	Arm Assembly	Arm Baugruppe
103	12B03555	Tampon	Feed Bumper	Puffer
104	12B03556	Goupille	Spring Pin	Stift
105	12B03557	Douille	Latch Spring Bushing	Buchse
106	12B03558	Goupille	Pin	Stift
107	12B03559	Roulement	Bearing	Lager
108	12B00039	Joint	O - Ring	O-Ring
109	12B03560	Support	Bracket	Halterung
110	12B03561	Guide ressort B	Spring Base B	Federführung B
111	12B03562	Ressort	Spring	Feder
112	12B03563	Guide ressort A	Spring Base A	Federführung A
113	12B03564	Plaque du bras oscillant	Swing Arm Plate Structure	Schenkarmplatte
114	12B03565	Glissière	Guide Slideway	Führungsschiene
115	12B03566	Support	Magnet Holder	Magnet halter
116	12B03567	Aimant	Magnet	Magnet
117	12B03568	Goupille	Spiral Pins	Stift
118	12B03569	Couteau	Driver	Treiber
119	12B03570	Impacteur	Impact Unit	Schlagvorrichtung
120	12B03571	Goupille	Pin	Stift
121	12B03572	Galet	Rolling Element	Laufrolle
122	12B03573	Roulement à aiguilles	Needle Bearing	Nadellager
123A	12B03574	Chassis	Frame Assembly	Montagerahmen
125	12B03575	Vis CHC M4-6	Hex.Soc.Hd.Bolt	Schraube
126	12B03576	Support moteur	Fan Motor Bracket	Motorhalterung
128	12B03577	Goupille	Pin	Stift
129	12B03578	Vis CHC M5-12	Bolt Assy	Schraube
130	12B03579	Goupille	Spring Pin	Stift
131	12B03580	Amortisseur	Bumper	Puffer
132	12B03581	Guide	Extension Pole	Führung
133	12B03582	Vis spéciale	Special Screw	Schraube
135	12B02735	Ressort	Spring	Feder
136	12B03583	Ressort	Latch Spring	Feder
137A	12B03584	Actionneur	Fuel Actuator Assembly	Stellantrieb

138	12B03585	Goupille	Pin	Stift
139	12B03586	Rondelle	Latch Spring Bushing B	Schraube
140	12B02558	Vis AHC M4-4	Hex.Soc.Hd.Screw	Schraube
141	12B03587	Goupille	Fixed Pin	Stift
142	12B00689	Goupille	Spring Pin	Stift
143	12B00401	Goupille	Spring Pin	Stift
144	12B03588	Vis	Hex.Soc.Hd.Screw	Schraube
145	12B03589	Ressort	Stopper Finger Spring	Feder
146	12B03590	Levier	Motor Fan Switch Lever	Hebel
147	12B03591	Arrêt	Stopper	Stopper
148	12B03592	Goupille	Pin	Stift
149	12B03593	Ressort	Spring	Feder
150	12B03594	Bobine de commande	Pusher Unit	Magnetspule
151	12B03595	Protection	Cover-Safety	Schutzkappe
152A	12B03596	Moteur	Motor Unit	Motor
157	12B03597	Couvercle	Cover	Deckel
158	12B03598	Vis	Hex.Soc.Hd.Bolt	Schraube
201	12B03599	Module électronique	Pcb Assmly	PCB-Baugruppe
202	12B03600	Régulateur de vitesse	Speed Regulator	Geschwindigkeitsregler
203	12B03601	Bouton de commande	Switch Buttom	Schalterknopf
204	12B03602	Contact gâchette	Trigger Valve Assy	Auslöseknopf
205	12B03603	Vis	Tap Bolt	Schraube
206	12B03604	Vis	Hex.Soc.Hd.Bolt	Schraube
207	12B03605	Gâchette	Trigger	Auslöser
301	12B03606	Couvercle	Cover Unit	Deckel
302	12B03607	Vis	Tap Bolt	Schraube
303A	12B03608	Coque droite	Gun Body Unit	Rechts Gehäuse
304A	12B03609	Coque gauche	Gun Body Unit	Links Gehäuse
306	12B03610	Crochet de ceinture	Spring Retainer	Gürtelhaken
307	12B00844	Vis	Tap Bolt	Schraube
401	12B03611	Couvercle	Guide Cover	Deckel
402	12B03612	Levier de loquet	Lock Handle	Schließgriff
403	12B03613	Goupille	Spring Pin	Stift
404	12B03614	Goupille	Spring Pin	Stift
405	12B03615	Goupille	Spring Pin	Stift
406	12B03616	Loquet	Latch Unit	Verriegelung
407	12B03617	Plaque avant	Driver Guide Cover	Vorderplatte
408	12B01599	Goupille	Pin Coiled	Stift
409	12B03618	Sécurité A	Safety A	Sicherung A
410	12B03619	Embout	Protective Casing A	Schützkappe
411	12B00149	Vis CHC M4-12	Hex.Soc.Hd.Bolt	Schraube
412	12B03620	Sécurité B	Safety B	Sicherung B
413	12B00048	Ecrou nilstop M4	Lock Nut	Mutter
414	12B03621	Plaque de guidage	Driver Guide	Treiberführung
415	12B03622	Goupille	Spring Pin	Stift
416	12B03623	Guide couteau	Driver Guide	Treiberführung
417	12B03624	Ressort	Positioning Spring	Feder
418	12B03625	Loquet	Positioning Sheet	Riegel
419	12B01076	Rondelle	Flat Washer	Scheibe
420	12B03626	Magasin B	Magazine B	Magazin B
421	12B00199	Vis CHC M5-16	Hex.Soc.Hd.Bolt	Schraube
422	12B00274	Ressort	Spring Unit	Feder
423	12B03036	Rail	Steel Channel	Stahlkanal
424	12B03627	Magasin A	Magazine A	Magazin A
425	12B00078	Ecrou nilstop M5	Lock Nut	Mutter
426	12B02663	Vis CHC M4-10	Hex.Soc.Hd.Bolt	Schraube
427	12B03628	Arrêt	Stop Nail Plate	Stoppen
428	12B03629	Poussoir A	Protecting Hood Cover	Kloben A
429	12B03035	Poussoir B	Pusher	Kloben B
430	12B03630	Ressort	Pusher Spring	Feder
431	12B00016	Goupille	Spring Pin	Stift
432	12B03631	Arrêt	Push Block	Anschlag
433	12B03632	Vis	Philip Screw	Schraube
434	12B03633	Embout de bardage B	Protective Casing B	Schützkappe B