



REF	CODE	NAME - NOM	REF	CODE	NAME - NOM
1	125F0285	Cylinder head - Tête de cylindre	33	125F0297	Tank - Cuve
2	125F0262	Screw - Vis	34	125F0298	Motor fan - Ventilateur
3	125F0113	Washer - Rondelle	35	125F0299	Cover-Protection
4	125F0263	O-ring - Joint	36	125F0102	Flange cross bolt-Vis
5	125F0264	O-ring - Joint	37	125F0300	Valve connector-Connecteur
6	125F0265	Packing - Joint plat	38	125F0007	Elbow - Coude
7	125F0266	Seat - Tête de cylindre	39	125F0301	Tube
8	125F0267	Valve seat - support de lamelle	40	125F0302	Tube
9	125F0268	Exhaust valve plate - Lamelle	41	125F0135	Regulator-Régulateur
10	125F0005	Valve plate - Lamelle	42	125F0138	Pressure gauge- mano
11	125F0088	Bolt - Vis	43	121644	Coupler - Coupleur
12	125F0270	Cylinder - Cylindre	44	125F0008	Elbow - Coude
13	125F0271	Piston rod - Piston	45	125F0303	Tube
14	125F0030	Piston ring plate - Bague	46	125F0090	Bolt - vis
15	125F0041	Ring press plate - Bague	47	125F0100	Plug - vis
16	125F0272	Crankshaft - Carter	48	125F0144	Pressure switch-Pressostat
17	125F0273	Bearing - Roulement	49	125F0106	Nut - Ecrou
18	125F0274	Crankcase - Carter	50	125F0245	Safety valve-valve de sécu
19	125F0275	Cover - Protection	51	125F0304	Coupler - Coupleur
20	125F0276	Cover - Protection	52	125F0129	Drain cock - Vis de purge
21	125F0277	Air filter - Filtre à air	53	125F0154	Tank feet - Pied
22	125F0016	Air filter - Filtre à air	54	125F0107	Washer- Rondelle
23	125F0278	Bolt - Vis	55	125F0134	Check valve
24	125F0279	Motor - Moteur	56	125F0305	Nipple- Ecou
25	125F0280	Bolt - Vis	57	125F450005	Solenoid valve
26	125F0296	Earth wire - Câble terre	58	125F0009	Elbow - Coude
27	125F0104	Nut - Ecou	59	125F0306	Tube
28	125F0108	Washer - Rondelle	60	125F0222	Nipple- Ecou
29	125F0117	Washer - Rondelle	61	125F0307	Coupler - Coupleur
30	125F0091	Bolt - Vis	62	125F418005	On/Off switch - Bouton
31	125F0209	Run capacitor - Condensateur	63	125F0308	Wire- Câble
32	125F0254	Cover - Protection	64	125F0309	Wire - Câble